

# IMPORTANT SITE PREP AND INSTALL INFORMATION

## **RE: PRO FLO© SYSTEM TANK ONLY**

---

### **PLEASE READ THIS IMPORTANT NOTICE:**

Thank you for ordering (or requesting information on) the Pro Flo© Aerobic Systems. Due to the considerable weight and increased size of the Pro Flo© tank, HCCP has issued these amended site preparation and install requirements unique to the Pro Flo© tank. Please be sure to read and observe the following site prep requirements and install information to assist us in safely delivering the Pro Flo© tank and to help avoid any unnecessary delays to your job. Please keep in mind that we must condition our express limited warranty (which is set out in our catalog and available for further review upon request) upon the installer's adherence to both the depth limitations and the bedding recommendations set forth in our product diagrams and site prep sheets (see items 1 and 2 below).

In considering and preparing for the installation of the Pro Flo© tank, please keep the following information in mind:

1. The Pro Flo© tank must never have more than 2 feet of cover over the lid.
2. The tank needs to be properly bedded with at least 6 inches of *washed sand* (a/k/a "river sand") or *washed gravel*, NOT "manufactured sand" or sandy loam.
3. The Pro Flo© tank as built by HCCP weighs approximately 18,000 pounds and requires special site conditions and access for HCCP to be able to safely handle and deliver the tank. All of the following conditions and access routes must exist at your job site:
  - A. The job site must be reasonably level, firm and dry with room to set our out-riggers **and rotate the load with our knuckle-boom truck.**
  - B. If there is any concern about your site, we will be happy to come look at it before you dig the hole to advise on our ability to access the site properly.
  - C. Please see our standard site prep sheet (attached) for other general information on the excavation.
  - D. Please keep in mind that we cannot unload off the side of the truck.